

## PRODUCT SPECIFICATION SHEET

# XL MOULD OIL AC

XL Mould Oil AC can be applied by spray, brush or by using a roller. For some surfaces, application by using a roller is the preferred method. The oil is used for coating the walls and floors of rectangular moulds before pouring aerated concrete.

XL Mould Oil AC is a high viscosity mould release oil for autoclave aerated concrete blocks.